


Part II - Installing the belt

VERSION 1.0



Step I : put the belt over generator pulley and fan housing pulley

Step II :- bring crank shaft pulley prepared with 6 bushes, flange ring and 6 screws in the lower part of the belt and push the pulley care fully downward untill bore of pulley is entering the flange surface

Step III :- fasten the 6 screws with

- finally check again that pulleys are coplanar with ruler

- turn the disc slightly for finding the threaded bores for the screws